HBlue Mountain Arts. ASSEMBLY INSTRUCTIONS


IF YOU HAVE QUESTIONS PLEASE CONTACT OUR CUSTOMER SERVICE DEPARTMENT AT: 1.800.525.0642					
BOX 1	В	lue Mounta	in Modula	r Merchandiser - Large	
PART Connector Hinge Kit Base Flange Screw Header Base Hex Wrench	QTY. 1 4 1 1	REF. A B C D E		NOTE: Header Graphic sent seperately!	
	A B	C			
BOX 2					
PART Upper Pole Lower Pole Wing Hubs Bearing Washer Cotter Pin	QTY. 1 1 18 3 3 3	REF. F G H I J K L			
		E			
		D			
	Enlarged Ima	G K age			

Blue Mountain Modular Merchandiser - Large Page 1 of 5

If you set up Multiple Fixtures together - START HERE If not connecting bases see page three

TOOLS REQUIRED: #2 Phillips Screwdriver

A Determine arrangement of fixtures. See sample configuration shown below.



Note: The Medium base hinge holes are offset so bases must be rotated until holes align.


Hinge

Hinge Pin

Bottom View


Base Bottom View

B Flip Bases (D) upside down and connect Hinge with (6) Screws from Connector Hinge Kit (A) into pre-drilled holes.



Remove Hinge Pins, from Hinges, flip Bases (D) back over.






Blue Mountain


Modular Merchandiser - Large

Page 2 of 5

LARGE DISPLAY ASSEMBLY


- 1 Attach Lower Pole (G) to Base (D) with (4)
 Base Flange Screws (B)
 using Hex-Wrench (E).
 - B B
- Remove Cotter Pin (L)
 from Upper Pole (F).
 Slide (1) Washer (K), (1)
 Bearing (J) and second
 Hub (I) over Upper Pole (F).






Install lower (9) Wings (H). Hook bottom (longer) prongs into the bottom Hub (I), then tilt up and hook upper prongs into middle Hub (I).

Note: Alternate Wings on either side of Hub to maintain balance.





TOP


(G)

Insert Upper Pole (F)

into Lower Pole (G)

until seated.

Replace Cotter Pin (L) into the hole at the top of Upper Pole (F). Slide (1) Washer (K), (1) Bearing (J) and third Hub (I) over Upper Pole (F) and onto pin at top of pole.



Blue Mountain Modular Merchandiser -


Page 3 of 5


LARGE DISPLAY ASSEMBLY

INSTALLING GRAPHICS


7 Install upper (9) Wings (H).
Hook bottom (longer) prongs into the middle Hub (I), then tilt up and hook upper prongs into top Hub (I).

8 To remove graphic covers from **Header (C)** reach into center of **Header (C)** and push tabs out through the opening







9 Turn **Header (C)** so side *without* trim is up as shown below. Keep other end of graphic cover hooked into header. Slide graphic under graphic cover until end of graphic is butted to the bend of tab at other end of cover.



Hook graphic cover tab back into slot on **Header (C)** to complete graphic installation.



(11) Lower Header (C) onto tower assembly as shown to the left.




lue Mountain Modular Merchandiser - Large


Page 4 of 5

To order Additional Wings contact:OUR CUSTOMER SERVICE DEPARTMENT AT 1.800.525.0642

ADDITIONAL WINGS

PART	Part #
Card Wing	55521
Book Wing	55522
Miniature/Magnet Wing	55523
Mini Book/Pocket Pad Wing	55524
Note Pad Wing	55525
Bookmark Wing	55526
Wallet Card Wing	55527





Blue Mountain Modular Merchandiser - Large Page 5 of 5